




EXTERNALLY ADJUSTABLE LIMIT SWITCH INSTRUCTIONS

WARNING: Adjustments to the upper limit switch will void the manufacturer's warranty.



- 1) MAKE SURE THAT THE PUMP AND MOTOR IS FULLY RETRACTED (DOWN ALL THE WAY).
- 2) PRY OFF THE SWITCH ADJUSTMENT COVER TO EXPOSE THE 1/2" HEX SWITCH ADJUSTMENT.
- 3) WHILE RUNNING PUMP, TURN SWITCH ADJUSTMENT COUNTER-CLOCKWISE UNTIL MOTOR SHUTS OFF.
- 4) TURN ADJUSTMENT CLOCKWISE WHILE RUNNING PUMP UNTIL LIMIT SWITCH IS SET AT DESIRED STROKE LENGTH.
IMPORTANT: DO NOT EXCEED MAXIMUM STROKE FOR PUMP.
- 5) RUN PUMP DOWN AND THEN BACK UP TO CHECK FOR PROPER HEIGHT.
IMPORTANT: MAKE SURE MOTOR SHUTS OFF COMPLETELY BEFORE REACHING THE PUMP MAXIMUM STROKE.
- 6) REPLACE SWITCH ADJUSTMENT COVER.

Distributed by Ergonomic Partners, Inc.
Email: sales@ergonomicpartners.com
Web: www.ergonomicpartners.com
PH: 314-884-8884 | FAX: 800-570-5584